

# WATER SPECIFICATION GUIDELINES

Unic USA is committed to precise extraction of all coffees used with our line of equipment. Precision extractions start with precision water delivery.

For best results using your Unic equipment, and to maintain warranty status (if applicable), we recommend the water supply meet the following specifications:

Water Component	Minimum Value	Maximum Value	Measured Value (pre-filter)	Measured Value (post-filter)
<b>TDS (Total Dissolved Solids)</b>	<b>50PPM</b>	<b>125PPM</b>		
<b>Total Hardness</b>	<b>3GPG</b>	<b>5GPG</b>		
<b>pH</b>	<b>6.5</b>	<b>7.5</b>		
<b>Free Chlorine</b>	<b>--</b>	<b>0.5PPM</b>		
<b>Total Chlorine</b>	<b>--</b>	<b>1PPM</b>		
<b>Flow Rate</b>	<b>1GAL/MIN</b>	<b>--</b>		
<b>Line Pressure</b>	<b>30PSI</b>	<b>100PSI</b>		

Due to the erratic nature of local water utilities, water supplied to your Unic should pass through a treatment system, even if pre-treated water meets all listed specifications. Water treatment systems should be checked and tested for accuracy every three months for the first year. This allows you to develop a custom system maintenance schedule and guarantees the best possible results with the least risk of damage to your Unic equipment.

If you have a written extended service arrangement with Unic USA, we will ensure that all guidelines are being met and, at our option, create a water treatment maintenance schedule most appropriate for your local needs for the duration of the agreed service arrangement.

If you do not have an extended service arrangement, please be sure to schedule a preventative maintenance visit with your local Unic service professional once every four months and provide this form to be completed at the time of service.

Submit completed form to: [usa.service@unic-sa.com](mailto:usa.service@unic-sa.com)

<b>Machine (Model):</b>		<b>Serial Number:</b>	<b>Water Treatment System:</b>	
<b>Machine Location:</b>		<b>Service Company:</b>		<b>Date of Installation:</b>
				<b>Date of Last Service:</b>
<b>Contact Person:</b>	<b>Phone:</b>	<b>Technician:</b>	<b>Phone:</b>	<b>Technician Signature:</b>